

Fig. 1

Fig. 2

Fig. 3

Fig. 4

Fig. 5

Fig. 6

Fig. 7

Fig. 8

Fig. 9

XT-50

XT-70

XT-75

XT-90

XT-200L Quick Charger

XT-200H Quick Charger

XT-200K Quick Charger

Parts List

Description	Model			
	XT-50	XT-70	XT-90	XT-75
Lens Ring	XT-312	XT-312	XT-312	XT-313
Glass Lens (standard)		XT-484		
Polycarbonate Lens (option)		XT-494		
Lens Seal		XT-348		
Switch Kit	XT-232		XT-233	
Lamp Stand		XT-410		
Lanyard		H-35SB		
Conductive Lanyard Zone 0				XT-427
Head Assembly	XT-210	XT-220		XT-220
Battery Pack	XT-202	XT-204	XT-206	XT-204
Body Assembly	XT-235	XT-237		XT-238

Fig. 10

Fig. 11

Fig. 12

Parts List

Description	Pt. No.
Charger Body Assembly	XT-281
Latch Mechanism	XT-282
Charger Circuit Assembly	XT-452
Spare Charger Fuse 2.5A	XT-225
Screw Kit	XT-283

Wolf

WOLFLITE XT RECHARGEABLE HANDLAMP

ATEX and IECEx Certified for Explosive Atmospheres

OPERATION AND MAINTENANCE INSTRUCTIONS

